

# INSTALLATION & ADJUSTMENT INSTRUCTIONS

**LETHAL WEAPON® 1 & 2 & MAX • QC™ 1 & 2**

## LIGHT KIT FOR LETHAL WEAPON® 1, 2, MAX & QC™ 1, 2

This fingertip controlled, brightness adjustable light can be mounted so it aims up or down on your fibers.

### Mounting instructions

#### On top shining down:

1. Place the light/bracket assembly on the top of the pin guard with the nose of the light pointing down.
2. Install the (2) 5-40 socket head cap screws and washers.
3. Tighten screws.

**Note:** When using a lens adapter/choke tube, mount the light on top with its nose toward the archer.

#### On bottom shining up:

1. Remove level and bracket.
2. Remove level from the bracket—retain the level and screws for the next step.
3. Install the level and screws to light/bracket assembly.
4. Place the light/bracket assembly on the bottom of the pin guard with the nose of the light pointing up.
5. Install the (2) 5-40 socket head cap screws and washers and tighten screws.



### Adjustable brightness operation

1. Press button to turn light on or off.
2. Press and hold button to control brightness.

#### From off:

- Release at desired brightness. Light will blink at full brightness.

#### From on:

- Release at desired dimness. Light will blink at lowest light level.
3. For safety beacons, patiently press button and hold past blink. You can choose slow beacon, medium beacon, fast flash, or S.O.S.

**Note:** If light turns on properly, but then turns off by itself, the light is in “demo” mode. To remove “demo” mode, turn light back on; then simply press and hold button until light turns off—about 20 seconds. Continue with normal operation.

# INSTALLATION & ADJUSTMENT INSTRUCTIONS

## LETHAL WEAPON® 1 & 2 & MAX • QC™ 1 & 2

### Battery replacement

1. Carefully pry up on the light housing and remove from bracket/cap.  
**Note:** The light housing detaches from the light cap and bracket assembly, which both stay on the sight.
2. Replace with (2) cr-2016 Lithium batteries. Install the (+) side toward the cap.  
Be sure top of battery is under the metal strap.
3. Replace the light housing and snap shut.

**Note:** In the event of water penetrating the light case, simply open the case and allow to dry.